HEN

BLADE® Nozzles

QUICK START GUIDE

1 Orienting the BLADE® to the shutoff

Rotate the nozzle until the BLADE® pattern insert (blue triangle) aligns with the shutoff handle, as shown. When the raised fin is in line with the BLADE® pattern insert the nozzle is in wide BLADE® mode.



Align with shutoff handle

2 Switching between solid blade and solid tight stream

For a solid tight stream turn the outer collar a quarterturn to the right. To return to the wide BLADE® or a stream width in between, rotate the outer collar back to the center line. For most applications, we recommend the BLADE® pattern.



A quarter turn right for tight pattern

3 Locking swivel

(if equipped)

Lift the knob up to unlock, then rotate the nozzle to a new position. The knob will fall into the new locking position. When it's flush with the nozzle body, set the lock by slightly moving the nozzle to engage.



Turn the knob to toggle between LOCK and UNLOCK

For any questions about your new HEN® nozzle, please contact:
(510) 751-2073 • support@hennozzles.com

30-0002-00 REV10