



BLADE™ Nozzles

QUICK START GUIDE

1 Orienting the BLADE™ to the shutoff

Rotate the nozzle until the blade pattern insert (blue triangle) aligns with the shutoff handle, as shown. When the raised fin is in line with the BLADE™ pattern insert the nozzle is in wide blade mode.



2 Switching between solid blade and solid tight stream

For a solid tight stream turn the outer collar a quarterturn to the right. To return to the wide BLADE™ or a stream width in between, rotate the outer collar back to the center line. For most applications, we recommend the blade pattern.



3 Locking swivel (if equipped)

Lift the knob up to unlock, then rotate the nozzle to a new position. The knob will fall into the new locking position. When it's flush with the nozzle body, set the lock by slightly moving the nozzle to engage.

